



ELAN

Straight Rail Stairlift

**Universal
Global
Design!**



 **MADE IN USA**

Sleek Efficiency



Quiet and Compact

Bruno's Elan is the ideal stairlift for today and tomorrow – rack and pinion drive delivers a ride which is smooth and quiet, while a handsome rail hides all mechanical components. In addition, the seat, armrests and footrest all fold up into a compact unit – family and friends will have no problem using the stairs.

Value

Elan offers a long list of standard features that are usually found only on more expensive units. The simplicity in design makes the Elan easier and less costly to install than other stairlifts.

Global Design

Meeting additional standards from around the world, the Bruno Elan Straight Rail Stairlift is the new benchmark for Style, Performance and Affordability. Building on two decades of Bruno research, the Elan can transport up to 300 lb with ease and in total comfort. Look to Bruno for the finest Home Accessibility solutions.



The arms, seat and footrest flip up, creating plenty of space to walk up the stairs.



The hidden, rack-and-pinion drive system provides a smooth ride, without hesitation, when the unit stops and starts.

ELAN
Straight Rail Stairlift

Durable Operation

Safety First

A dual braking system makes the Elan one of the safest stairlifts in the world. The electromagnetic braking system is complemented by a self-locking gear box and overspeed brake which completely ensures your safety. Safety sensors on the foot plate and carriage stop the unit whenever an obstruction is encountered.

Consistent Power

The Elan uses two 12-volt batteries that are powered by a low-profile charger that plugs into any household outlet. A continuous charge along the rail is provided through a full-length charge strip. Access to upstairs and downstairs is never an issue, even when there is a power outage.



Elan Features



The convenient offset swivel seat mechanism provides a safe, comfortable exit at the top of the rail.



Continuous charge strips along the entire rail, mean the unit will be charged wherever it stops on the staircase.



The vertical straight rail can be installed to within 5" of the wall, and when the armrests, seat and footrest are folded, the Elan carriage takes up only 12".



The two wireless call/send controls make installation simple and clean with no wires running along the wall.

Model SRE-3000

Elan SRE-3000 Specifications

Exceptional Value

- Locking offset swivel seat at the top of the stairway - stops at 67° and 90°
- Two remote, wireless call/send controls
- Flip-up footrest
- Footrest and carriage safety sensor
- Seat belt with buckle
- Audio diagnostics makes service easier and more precise
- Conforms to ASME Std. A18.1 and A17.5
- Certified to CSA Std. B613 and B44.1
- ETL Intertek C/US listed
- Bruno's Gold Warranty – Five years on major components and two years on parts

Convenient Installation

- Anodized aluminum rail installs to within 5" (127 mm) of the wall
- Can be installed on either side of the stairway
- Standard track length of: 15' 9" (4.8 m) – two 7' 10.5" (2.4 m) sections
- Optional track length of: 19' 8" (6 m) – two 9' 10" (3 m) sections
- Optional track length up to 31' 6" (9.6 m)

Smooth, Powerful Drive System

- Self-locking worm gear, rack-and-pinion drive with electromagnetic braking system and overspeed brake
- Maximum rider weight of 300 lb (136 kg)
- Soft-start provides smooth operation

Battery-Powered Technology

- Ensures access even during power outages
- Powered by two 12V batteries; continuously charged by a 1A battery charger that plugs into any 110V household outlet
- Full-length charge strip allows unit to charge anywhere along the rail

Comfort

- Adjustable seat height for easier entry/exit at the top and bottom of the stairway
- Flip-up arms for easy wheelchair transfers
- Generous seat size – 17.5" (444 mm) seat pad width & 20" (508 mm) width between the arms
- Contoured seat for maximum comfort

Ask us about our other... **Home accessibility solutions and automotive products**



OUTDOOR ELITE

The only 400 lb/181.8 kg capacity outdoor stairlift... an INDUSTRY EXCLUSIVE!



VERTICAL PLATFORM LIFT



VEHICLE LIFTS



VALET™ SIGNATURE SEATING

Founded over 25 years ago, Bruno Independent Living Aids, Inc., is a world-wide manufacturer of accessibility products designed to enhance the lives of those challenged by limited mobility. In pursuing this goal, Bruno is proud to be the only U.S. manufacturer of indoor/outdoor stairlifts, interior/exterior scooter, powerchair and wheelchair vehicle lifts and vehicle seating products to be ISO 9001 Certified. This is one of the most stringent, widely-recognized quality standards in the world and your assurance that Bruno is committed to providing you with the highest-quality, most reliable products in the industry. Ask your certified Bruno dealer for details on all Bruno independence products.

Represented by:



BRUNO INDEPENDENT LIVING AIDS, INC.®
1780 Executive Drive, Oconomowoc, WI 53066
www.bruno.com



All illustrations and specifications in this brochure are based on the latest product information available at the time of publication. Bruno Independent Living Aids, Inc. reserves the right to make changes at any time without notice.

© Bruno Independent Living Aids, Inc. 2013. 2013-9-3_SRE-3000 Elan Brochure.indd

Part#: MKT-SRE-3000